

Xbee standalone node circuit
 Carol LaFayette, 2012, made with Fritzing
 The LEDs are good for testing but you may want
 to remove them before deployment, because they
 can trigger the PIR sensor.

